


FUEL SYSTEM

Remove the over flow tubes and air vent tube.
Remove the four float chamber screws and the float chambers.




FLOAT LEVEL

Measure the float level with the float tang just contacting the float valve.


SPECIFICATION: 18 mm (0.71 in)

Adjust the float level by carefully bending the float tang.



FLOAT, FLOAT VALVE AND JETS

Remove the float pin, float and float valve.



Inspect the float valve and its seat for grooves, nicks, or contamination.

Inspect the operation of the float valve.

Check the float for deformation or presence of fuel.

